




MINI PLAYFIELD REMOVAL




Mini Playfield Pivot link

REMOVE the 1/4" Hex head screws
on both LEFT and RIGHT side of
the Mini playfield






**Remove the Phillips head screw
securing the pivot link**



Located mini playfield harnesses and disconnect.



Once all the hardware has been removed and the Mini playfield harnesses are disconnected, carefully raise the mini playfield away from the pivot brackets. This should give you access to the mini playfield harness and allow more room to disconnect the harness from the mini playfield.